



Agrumino Lemon Dev Guide rev 0.4 _ENG

Autore: LifelyTeam Versione: March 2021











|1|-



IMPORTANT

Before using the device, charge the battery and make sure that the jumper located next to the battery is correctly positioned.

If you have any problems with the configuration, please contact info@lifely.cc.













1 Introduction

This document provides a guide to install Agumino Board and its libraries. Moreover it describes some example sketches, part of the Agrumino libraries.

2 Installation

2.1 Install the USB driver

Modern Windows installations seem to automatically install the USB driver. If you're on another platform, like Mac OS/Linux/Android or Windows, which doesn't recognize the Serial Port automatically, you can download the official driver from here: <u>CP2102 Driver</u>.

2.2 Install the Agrumino Board on Arduino IDE

The Agrumino board is based on an ESP8266 WiFi chip. The official programming environment is Arduino, this is possible thanks to the Open Source project <u>ESP8266 Core</u> for Arduino. We have forked this project and created a custom Agrumino core that includes all the libraries needed by the example sketches to ease the installation procedure.

Arduino allows installation of packages using Boards Manager. The package is available for Windows, Mac OS, and Linux (32 and 64 bit).

- 1. Install the current upstream Arduino IDE at the 1.8 level or later. The current version is available at the Arduino website.
- 2. Start Arduino and open File->Preferences window.
- 3. Enter this URLs comma serparated

https://raw.githubusercontent.com/lifely-cc/arduino-ison-manifest/main/package_lifelycom_index.ison 。 http://arduino.esp8266.com/stable/package_esp8266com_index.ison

into Additional Board Manager URLs field. You can add multiple URLs, separating them with commas.

 Open Boards Manager (Tools → Board → Boards Manager...) and install Lifely Agrumino Board platform (and don't forget to select your Agrumino board from Tools → Board menu after installation).

You can find the official guide, plus additional installation options, here: <u>Arduino core for</u> <u>ESP8266</u>.













2.2.1 If you have problem with setup in step 2.2

- 1. Start Arduino and open File->Preferences.
- 2. In text box "Additional Board Manager" URLs write this : http://arduino.esp8266.com/stable/package_esp8266com_index.ison
- 3. Open(Tools→Board→Boards Manager...) in the text box type ESP8266 and click install.
- 4. Now select from Tools→Board "Generic Esp8266 Module" and after go to Flash size and select 2MB (FS:none OTA:~1019KB)
- 5. Download Agrumino libraries from https://www.lifely.cc/download/agrumino-libraries/
- 6. On Arduino IDE click Sketch→Include Library add ZIP Library and select the downloaded file (Agrumino.zip).

<u>To verify correct installation go to Arduino \rightarrow Examples \rightarrow Agrumino and try to upload a sketch.</u>

2.3 Install the Agrumino libraries on Arduino IDE

The official *Agrumino* library comes together with the core installation. We provide a list of the libraries below only as a reference. **You don't need** to install any library.

- <u>WiFiManager</u> (2.0.3-alpha)
- <u>ArduinoJson</u> (6.15.2)

Thing Speak Json Post

• <u>NTPClient</u> (master 9beb84ba50ce37d4c60b08574e1c37b6f598cb6c)

OTA web:

- <u>ESPAsyncWiFiManager</u> (master bf342327f2fd0f0518bf4932b50c04732063b8d1)
- <u>ESPAsyncTCP</u> (master 15476867dcbab906c0f1d47a7f63cdde223abeab)
- <u>ESPAsyncWebServer</u> (master f13685ee97675be2ac9502d177d3024ebc49c1e0)
- <u>AsyncElegantOTA</u> (2.2.2)













3 Programming the board

The Agrumino Board can be easily programmed by pressing the "Upload" button on the Arduino IDE.

Be sure to select "Agrumino Lemon v4 (WT8266-S1 Module)" as a Board in the (Tools \rightarrow Board) menu.

4 Arduino library usage

4.1 Examples using USB flashing mode

On this paragraph, example sketches of the Agrumino library are briefly presented. Notice that they are divided into three folders: QuickStart, Cloud, OTA and Advanced (File \rightarrow Examples \rightarrow Agrumino).

Accessing Wifi network

Concerning Cloud and OTA sketches, it is necessary to connect Agrumino Board to the wifi network. After uploading the sketch on Arduino IDE:

- 1. the board is setted up in Station mode and tries to connect to a previously connected Access Point
- In case of unsuccess of point 1 (or in case of unsaved Access Point) the board is moved into Access Point mode and spins up a DNS and a Web Server (default ip 192.168.4.1, copy it from Serial Monitor)
- 3. using any wifi enabled device with a browser (computer, phone, tablet) connect to the newly created Access Point (which has a SSID such as Agrumino-XXXXX, where XXXXX is a number)
- 4. Write IP of DNS server on your web browser and click on 'Configure Wifi'. Choose one of the access point scanned, enter password and click save
- 5. Agrumino will try to connect. If successful, it stops control back your app. If not, reconnect to AP and reconfigure.

Further informations at official library page: WifiManager.

4.1.1 QuickStart examples

Sketches to check basic feature of Agrumino, like reading sensor data, saving data on flash memory and check wifi connection.

• AgruminoSample

Simple sketch to read all the values from the Agrumino Board and print them in the serial console every 30 sec.

AgruminoBringUp
 Simple sketch to test Agrumino board and FLASH Memory of ESP8266 Module. In













particular it is possible to read all the values of sensors and print them in the serial console. Moreover it is possible to clean, read, write and commit on memory to verify its integrity.

• WifiClient (ESP8266 example)

Sketch to check wifi connection. It is necessary to fill STASSID and STAPSK with personal wifi SSID and password.

4.1.2 Cloud examples

Sketches to send sensor data of Agrumino board to various cloud backends. All the sketches use deep sleep to save energy and keep a queue of samples in EEPROM (flash).

• AgruminoDweet

Sketch that reads every 1h all values from the Arduino board and update them to the Dweet.io service every 4h. It integrates FLASH management to collect all data before transmitting them. More details <u>here</u>.

• AgruminoThingSpeakHttpPost Same as the AgruminoDweet sketch but data are sent to the <u>Thing Speak website</u> with 4 different Http Post.

• AgruminoThingSpeakJsonPost Same as the AgruminoDweet sketch but data are sent to the <u>Thing Speak website</u> with a single Json Post.

4.1.3 Advanced examples

Sketches that explore the usage of Agrumino with third-parties sensors, actuators, boards such as oled display, water pump and so on.

AgruminoOledSample

4.1.4 OTA flashing to update firmware examples

Sketches that send sensor data to the cloud and at the same time demonstrate the usage of Over The Air updates.

AgruminoDweetWebOTA

This sketch is the same as the AgruminoDweet sketch moreover integrates the update of the firmware via OTA using a web page. Users can choose an executable from pc and upload it on the board using the address of the board.

AgruminoDweetHttpOTA

This sketch is the same as the AgruminoDweet sketch moreover integrates the update of the firmware via OTA using a remote HTTP server. Each time the executable (.bin) loaded on the server is updated, the board downloads it automatically.













5 Hardware components

In the following paragraph are underlined the principal components of Agrumino Board, front and back sides. It is possible to see an interactive image at lifely page (<u>link</u>).

5.1 Agrumino board front













|7|-



5.2 Agrumino board back



I2C Connector and GPIO Connector are compatible with the <u>Grove System</u>. Grove I2C and Grove Digital are supported out-of-the-box while Grove Analog can be used with an external <u>Grove-I2C-ADC</u>.

6 Open issues

 JST-PH connector seems to be different from the Grove even if they fit well (see DigiKey <u>1597-1083-ND</u>).

7 Future development

- Watering with time duration
- Expose PCA9536 GPIO 2-3-4 Pins

8 FAQ & Common Errors

1. error: cannot access ...

Check from the (Tools \rightarrow Port) menu that the selected board is the correct one and that it's connected.

2. espncom sync error

Press the reset button on the Agrumino (S2 on the Top-Left) and try again.













If the error happens again disconnect the Agrumino from the USB, remove and reconnect the jumper P1 and try again.

Visual Guide

In the first place install Arduino IDE from this link on your Pc, Notebook or Mac <u>https://www.arduino.cc/en/software</u>

After installing the Arduino Ide, connect Agrumino to your PC/MAC with micro usb cable and go to the next step.

Open Arduino IDE and go to File \Longrightarrow Preferences, and click $\overset{\sim}{\bigvee}$









Now in text box "Additional Boards Manager URLs" copy and paste this this link:

https://raw.githubusercontent.com/lifely-cc/arduino-json-manifest/m ain/package_lifelycom_index.json



n Tam Hep				
10 2				
> (
at being cost perel av tat outer				
B	Pediatects		*	
ur main code here, in sin repeatedly:	Settings Hechwark			
	Skelidarsk koalten			
	C Usersigabil OreDrive/Documents/Arduma		Browse	
	Driter increase: System Default	(secures restart of Assure)		
	Editor ford sizes 12			
	Interface state: Di Automatic 100 C N	Subscience matastrof Arciano)		
	these Defaid Boose - Orio	instantian and an instantian		
	Show verbore output during: Coordiation Caloe			
	Complex warnings None w			
	Osplavine numbers	Brable Code Folding		
	El verify code after upited	Use extensi editor		
	C Grack for updates on startup	Save when writing or calcuding		
	Une accessibility features			
	Additional Boards Manager URLs: Mtos: //Yaw.githubuse	context.com/lifely-cc/arduino-jaan-manifest/inain/package_lifely.com_index.ja	× 🖾	
	Place professionar carries suffici develop in the Na			
	C: Users (pibr/#ppData Local Actuats 15 preferences. bo			
	[Ear out was was and many		Concerning and the second second	
			Oli Cenal	







Auto Format	Citl+T		
Archive Sketch Fill Encoding & Related			
Manage Libraries Secial Monitor Social Platter	Chi+Shit+I Chi+Shit+M Chi+Shit+L		
WEITOT / WIFEBANA Firm	wen Updater		
ESP Exception Decoder ESP8266 Sketck Data Up	owd		
Exand: "Andrene Yor"	1	Boards Moragar	
12 Post Get Based Info		Andraine AVR Boards) CSP32 Andraine (in allerchibeck) //	
Programmen "AVRISE m Bum Bootloader	ar i		

In text box write agrumino and click $\stackrel{\stackrel{}}{\smile}$ Install. After installing click $\stackrel{\stackrel{}}{\smile}$ Close

🗢 skatab, novilla (Andaina 18:12		- 0 ×
		a la
Skeldt_novrt Kala		
<pre>mail setup() { // put your avong both hand, to may moved vail loog 0 { // put your main, cole here, to may separately; } }</pre>	C fourth Mersger X	
1	Tore Marcine During Synamed	
	Cia	

Go to Tools Board Esp8266 Boards (2.7.1)

akatch_nov18a (A le Edit Skatch To	Arduine 1.8.13 2016 Help					
sketch_nov185	Auto Format Archive Sketch Fix Encoding & Reload	Ctrl+T				
will secup()	Senal Monitor Senal Plotter	Ctrl+Shift+M Ctrl+Shift+L				
	WiFi101 / WiFi11844 Firmware	Updates				
// put your	ESP Exception Decoder ESP8266 Sketch Data Upload					
weid imop() [// pat your	Board: "Anduine Yán"	1	Boards Manager			
	Post Get Board Info		Arduino AVR Boards > ESP32 Arduino (in sketchbook) >			
	Programmen "AVRISP mkl" Bum Bootloader		ESP8260 Boards (2.7.1)	Agrumino Lamon v4 (W18266-S1 Module)		

libraries/esp_mgtt-master libraries/algorithm_by_RF prary found in C:\Osers\o m_by_RF: no he ders Elles (.h) fo

If the choice was successful, you should see "Agrumino Lemon" at the bottom right on Arduino Ide

🕞 skonch, rovel la (Astráne 1.8.1)	- σ ×
Chi tak Sketh Toola Hap	1
stetti nortia	a l
VIIA etcay() // pat your weing tone here, to man more?	
31	
<pre>wead loop10 (// put your main code Sets, to run repeatelly: // put your main repeatelly: // put</pre>	
1	
Invalid Library Found in SiVDerra/gabei/OneCriva/Documents/Andain/librarie/vep.mgtb-master: no beeders files (.b) found in SiVDerra/gabe Tamaid Library Found in SiVDerra/gabei/OneCriva/Documents/Andain/librarie/vep.mgtb-master: no beeders files (.b)	rt/Gredictyw/hOccuments/Archites/Lithurstee/Leng.mgth-marter
Invalid Library found in C//Weersymber/OneEe/we/Dormments/Andmin//Libraries/segrant-master: no beskern files (.h) found in C//Weersymber/ Invalid Library found in C//Weersymber/OneEe/we/Dormments/Andmin//Libraries/segrant-master: no beskern files (.h) found in C//Weersymber/ Invalid Library found in C//Weersymber/OneEe/we/Dormments/Andmin//Libraries/segrant-master: no beskern files (.h) found in C//Weersymber/	rl/OnelRcive/Doromeents/Acoulto/Librarites/esp_pugt-meeter rl/OnelRcive/Doromeents/Acoulto/Librarites/algorithm.jpg_BF
	Appendix Lanco #70(79/20-S1 Massacray COX19

Now let's open a example sketch to upload it to your Agrumino

-|15|-

Click this button to open Serial Monitor (look at arrow 1) after, change baud rate to 115200 (look at arrow 2) and now you can see the board data (look at arrow 3)

Aprastini Estraja (Anhaire 1.1.1)		- a ×
No Di Cali Neo		- 13
Agruei/educate		1
winslude «Agrowing.h»	1.cl	1/1
egefine SIZEF_THE_SEC 20	COM19	×
Agrumino agruminos	1	Send
<pre>state.seque() { when leg()(IDDDD) yepted.set()(IDDDD) yepted.set()(IDDD) yepted.set()(IDDD)</pre>	Turning Name Inc. Institution and the second secon	
i international and the second secon	E seere Ore wase.	21
blinkled()r		
undo-desended Tiann Film (de Beaung film (din avy sak - dild) Ong rease regission demonsfilm). Compared (filed byges to another) Compared (filed byges to another) Demonstrate (filed byges to another)		
26-32		Agazana Lanas - A (WT2200 ST Mostale) on COMU

Congratulations

